



External Dimensions of PAC-SA52AG (ATR-Guide)






PAC-SA52AG ATR-Guide for PU(H)



Аетом шуматъ не обѣзгаТевнѡ.

\* For PU(H) - 4/5/6HP  
 please install this 2 pcs.  
 Due PU(H) - 4/5/6  
 шумико геранобуто 2 шт.



①	②	③	④	⑤
			M5 × 10 	4 × 10 
1枚	2枚	2本	4本	10本

Installation:

