








How to Use / How to Install

For 2-fan type outdoor unit, two pieces are required.


1 Checking parts

Make sure that all the following parts, in addition to this manual, are in this box:


① Front plate	1	② Side plate	2	③ Side plate	2	④ Connecting plate	2	⑤ Mounting screw 5 × 3.5	4	⑦ Spacer	4	⑨ Washer (for screw ⑤)	4
				※Only for PAC-SG56AG-E 				※Only for PAC-SG57AG-E 		※Only for PAC-SG57AG-E 		※Only for PAC-SG57AG-E 	
								⑥ Mounting screw 4 × 1.0	4	⑧ Mounting screw 4 × 1.2	4	⑩ Washer (for screw ⑧)	4
								For PAC-SG56AG-E	1				
								For PAC-SG57AG-E	6				

2 Requirements of space for installation

(1) One unit installation:




(2) Multiple unit installation: ※Installation of multiple units in series must be no more than five units.




3 Installation procedure

For RP1.6, 2, 35, 50




● Fix side plates ② and ③ (two each) using four screws ⑥ and attach them to outdoor unit using holes on side plate ③.

For other models:




● For RP2.5~6, 60~140, remove the four screws securing fan guard from its circumference.


● Attach two side plates ② to outdoor unit using four screws ⑤.




● Attach two connecting plates ④ to side plate ②, using four screws ⑧ with four washers ⑩.



● Attach two connecting plates ④ to side plate ②, using four screws ⑧ with four washers ⑩.



● Attach front plate ① to side plate ②, using six screws ⑥.



● Attach front plate ① to side plate ②, using six screws ⑥.